ARTISAN HYBRID TILES



Artisan Hybrid Tiles Care & Maintenance Guideline

While Hybrid floors are 100% waterproof it remains important to care for them as you would preserve and prolong the quality flooring surface for years.

Artisan Hybrid Tiles Recommends:

- Vacuum or sweep the floor on a regular basis or as needed to remove dirt, sand, or grit.
- For general cleaning, use PH neutral floor cleaner & microfiber mop.
- Fit furniture legs with felt tips/protective caps.
 Fixing rolling furniture with soft rubber casters.
 Pick up heavy furniture or appliances; do not slide
- Keep pet nails trimmed to avoid excess scratching.
- Avoiding exposure to excessive natural and artificial UV light through the use of curtains and blinds.
- Do not steam mop or pour liquid directly on the floor. Too much water may allow seepage through the click profile and will create a moist environment under the floor planks.
- Never use any of the following products on your floor: ammonia-based cleaners, mineral spirits, acrylic finishes, wax-based products, detergents, bleach, polishes, oil soap, abrasive cleaning soaps, or acidic materials such as vinegar.
- Never apply wax treatments to your floor.
- Use interior and exterior doormats at entrances to prevent dirt and moisture from being tracked onto the floor. Area rugs are also recommended in front of kitchen sinks and in high traffic areas.
- Rugs made of a breathable material will best prevent moisture entrapment. Mesh or grid patterns are best.

What is the best way to mop my Hybrid Floor?

Damp moping is allowed for our Artisan Hybrid Tiles. You may periodically use a medium dampened mop to maintain and clean the floor. We recommend using BONA or LOBA Vinyl floor care solutions; these are available from reputable flooring retailers. Consult instructions before use.

How can I protect the finish of my Hybrid Floor from wear over time?

Sweep and vacuum your floor regularly using a broom or dust mop. Brushes or felt vacuum heads are recommended as opposed to vacuums with beater bars or hard heads. Use throw rugs both inside and outside doorways to prevent debris from being tracked onto floors. Keep pet's claws trimmed to avoid excess scratches. Avoid contact with excess moisture. Avoid walking on your floors with cleats, sports shoes and high heels. Do not slide heavy furniture or appliances across the floor.

What are the best environmental conditions for my Hybrid Floor?

As a general rule, with geographic exceptions, flooring will perform best when the interior environment is controlled to stay within a relative humidity range of 35% to 65% and a temperature range of 18° to 26° Celsius. (In some climates, the ideal humidity range might be higher or lower) It is the owner's responsibility to maintain appropriate conditions via the use of humidifier and/or dehumidifier. In homes in which occupants are there for a short period of time (weekend home or vacation cabin), or in rooms that are closed off (not heated or air conditioned) to save energy, Ventilation is a must even when the home is not occupied.

ARTISAN HYBRID TILES



Artisan Hybrid Tils Care & Maintenance Guideline

How do I fix a scratch on my finish?

If the scratch is white, the top coat has not been compromised and is repairable. Simplay using a flooring cleaner, should eliminate these blemishes. If the scratch is deeper but was not exposed the SPC core, light buffing with a white polishing pad can shine up the dull area, often the damage becomes less obvious. When removing stains from any laminate floor, always begin at the outer edge of the stain and work toward the middle.

My Floor was damaged through the finish, can it still be repaired?

If you have a minor chips or slight damage, this may be minimized with a colour was stick. If the damage is severe enough, board replacement is typically the best option. In most cases, more than one shade may of colour was stick be appropriate.

Can I refinish my Hybrid Flooring?

No, it will damage the floor and void the warranty.

Can I put heavy furniture on floated flooring?

Ultra-heavy furniture (800kg+) may obstruct the free, natural movement of a floating floor. It won't affect the overall performance of the Hybrid Floor, but will restrict the movement in certain areas and may lead to problems such as buckling or separation between boards.

Occasional Flooring Noise?

Floor noise is normal and will vary from one installation type to another. Occasional noise is due to structural movement and may relate to subfloor type, flatness, deflection, and/or related to the fasteners, changes in environmental conditions, relative humidity and the amount of topside pressure applied to the flooring. For these reasons floor noise is not considered a product or manufacturer defect when the floor experiences natural expansion and/or contraction.